

ZOOM H-Series ASIO Driver Installation Guide

(Windows)

Copyright(C) 2013 ZOOM Corporation. All Rights Reserved.

ver2.0.0

● **Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.**

The actual content of screens and messages on the computer may differ from the illustrations used in this manual.

<Contents>

Introduction.....	3
Operation Environment Requirements.....	3
Precautions.....	3
Updating the driver.....	4
Installation.....	5
Uninstallation.....	11

Introduction

Thank you for downloading the ZOOM H-Series Driver.

This document describes how to install and uninstall the driver.

Operation Environment Requirements

Operating system: Windows® Vista SP2 later(32bit / 64bit) / Windows® 7 later(32bit / 64bit)/
Windows® 8 later(32bit / 64bit)

Precautions


- 1) Start installation and uninstallation disconnecting H-Series from PC.**
- 2) Before starting this application, shut down all other applications that are running.**

Updating the driver

If a ZOOM H-Series Driver is already installed, first uninstall the old driver.
Then install the new driver.

Installation

1. Start Windows without any USB devices including H-Series (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Double-click on the "H-Series_ASIO32.exe" icon or "H-Series_ASIO64.exe" icon depending on the operating system you use.



32bit




64bit


4. Select language and click [OK].




5. To start the installation, click [Next].




6. The License Agreement is displayed. Read the agreement and place a check mark in the “I accept the terms in the License Agreement” box to confirm your acceptance of the agreement. Then click [Next].




7. To start the installation, click [Install].



When a warning message “Windows security” appears, click [Install].



8. Click [Finish] to finish installation of InstallShield.





9. Next, connect the H-Series to the computer using a USB cable.

H1 : Press [REC] key while “AUdIo” is displayed.

H2n/H4n : Select [AUDIO I/F] from USB menu.

H6 : Select [Audio Interface] from USB menu and select [Stereo Mix].

When H-Series is connected to Computer, “Installing device driver software” will launch and it finish automatically.




Uninstallation

1. Start Windows without any USB devices including H-Series (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Click on the Start→Programs→ZOOM→H Series→" Uninstall ZOOM H Series Audio Driver " icon.



4. The uninstallation process starts. Confirm that you want to proceed by clicking [YES]. To cancel the process, click [NO].



*The uninstallation is completed automatically.