

ZOOM TAC-2 Driver

Installation guide

Copyright(C) 2016 ZOOM Corporation. All Rights Reserved.

- Zoom Corporation will bear no responsibility for losses or claims from third parties that result from the use of this software. Moreover, without our permission, distributing, selling, leasing, renting, altering or reverse engineering of this software is prohibited. Furthermore, the specifications of this software and the contents of this document could be changed without notice in the future.

- Macintosh and Mac OS are trademarks or registered trademarks of Apple Inc.
 - Thunderbolt and the Thunderbolt logo are trademarks of Intel Corporation in the U.S. and/or other countries.
- Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The illustrations in these instructions might differ from actual screens.

Contents

1. Introduction	2
2. System Requirements	2
Precautions	2
3. Updating the driver	2
4. Installation.....	3
5. Uninstallation.....	5

1. Introduction

Thank you very much for downloading the ZOOM TAC-2 Driver for the TAC-2 and TAC-2R.

This document explains how to install and uninstall the ZOOM TAC-2 Driver.

2. System Requirements

OS: Mac OS X 10.9.5 (or later)

Precautions

- 1) Start installation and uninstallation disconnecting TAC-2/TAC-2R from Mac**
- 2) Before starting this application, shut down all other applications that are running.**


3. Updating the driver

If a ZOOM TAC-2 Driver is already installed, first uninstall the old driver.


Then install the new driver.

4. Installation


1. Double-click on “ZOOM TAC-2 Driver.pkg”.
2. To start the installation, click [Continue].




3. To start the installation, click [Install].



After the installation of the driver is complete, the Mac must be restarted. Click [Continue Installation] to install the software.




4. After installation completes, click [Restart] to restart the Mac.



5. Uninstallation

1. Double-click on “ZOOM TAC-2 Driver Uninstaller”.
2. The uninstallation process starts. Click [Uninstall] to uninstall the software. After uninstallation, the computer must be restarted.



3. After uninstallation completes, click [Restart] to restart the Mac.

