

# ZOOM UAC-2 Driver Installation Guide (Mac)

Copyright(C) 2016 ZOOM Corporation. All Rights Reserved.

**●Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.**

• Macintosh® and Mac OS® are trademarks or registered trademarks of Apple Inc.

Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The illustrations in these instructions might differ from actual screens.

## Contents

<b>1. Introduction</b> .....	2
<b>2. System Requirements</b> .....	2
<b>Precautions</b> .....	2
<b>3. Updating the driver</b> .....	2
<b>4. Installation</b> .....	3
<b>5. Uninstallation</b> .....	5

## 1. Introduction

Thank you very much for downloading the ZOOM UAC-2 Driver for the UAC-2.  
This document explains how to install and uninstall the ZOOM UAC-2 Driver.

## 2. System Requirements

Mac : Mac with a USB 3.0 port  
OS: Mac OS X 10.9.5 (or later)  
USB: USB 3.0/USB 2.0  
(Operation is not guaranteed when used with USB hubs or expansion cards.)

### **Precautions**


- 1) Start installation and uninstallation disconnecting UAC-2 from Mac**
- 2) Before starting this application, shut down all other applications that are running.**

## 3. Updating the driver


If a ZOOM UAC-2 Driver is already installed, first uninstall the old driver.  
Then install the new driver.

## 4. Installation


1. Double-click on “ZOOM UAC-2 Driver.pkg”.
2. To start the installation, click [Continue].



3. The License Agreement is displayed. After checking the contents carefully, if you agree to them and will use the software, click [Continue].




Click [Agree].



4. To start the installation, click [Install].


To change the disk where the software is installed, click [Change Install Location...].



After the installation of the driver is complete, the Mac must be restarted. Click [Continue Installation] to install the software.




5. After installation completes, click [Restart] to restart the Mac.



## 5. Uninstallation

1. Double-click on “ZOOM UAC-2 Uninstaller”.
2. The uninstallation process starts. Click [Uninstall] to uninstall the software. After uninstallation, the computer must be restarted.



3. After uninstallation completes, click [Restart] to restart the Mac.

