

## G1on/G1Xon/B1on/B1Xon

### v1.21 Firmware Update Guide For Mac

Copyright(C) 2017 ZOOM Corporation. All Rights Reserved.

● Zoom Corporation will bear no responsibility for losses or claims from third parties that result from the use of this software. Moreover, without our permission, distributing, selling, leasing, renting, altering or reverse engineering of this software is prohibited. Furthermore, the specifications of this software and the contents of this document could be changed without notice in the future.

Macintosh®, Mac®, Mac OS®, OS X® and macOS® are trademarks or registered trademarks of Apple Inc.

Note: Other Product names, registered trademarks and company names in this document are the property of their respective companies.

Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The explanatory illustrations in this manual might differ in appearance from the actual screens on the unit.

#### 1. Supported operating systems

Mac® OS X® 10.10.2 (or later)

##### Important preparations

**1) Log in to your Mac using an account with administrator privileges.**

2) Before launching this application, quit all other running applications.

## **2. Introduction**

Thank you very much for downloading the firmware update application for the G1on, G1Xon, B1on and B1Xon.

This document uses the G1Xon for examples to explain how to update the firmware for the G1on, G1Xon, B1on and B1Xon.

## **3. Checking the firmware versions**

Follow these procedures to check the firmware version.

1. Start the G1Xon.
2. Press the MENU key to open the menu screen.
3. Move the cursor to VERSION and press ENTER key.

If the SYSTEM version is v1.21 or higher, you do not need to use this application to update the firmware. If the system version is lower than v1.21, follow the procedures below to update the firmware.


## **4. Updating the firmware**

Before updating the firmware, if any MIDI or audio devices are connected by USB cable to the Mac you are using, disconnect them all. In addition, if any applications are running, quit them all.


- 4.1. When the G1Xon power is OFF, while pressing and holding both the up and down cursor keys, connect its USB port and the computer with a USB cable.

This operation puts the G1Xon into a state ready to receive a firmware update, and its display shows a firmware update standby screen.

- 4.2. Double-click the firmware update application icon to launch it.  
After launching, a window that looks like this appears.




- 4.3. Confirm that "ZOOM 1 Series" appears in both the "MIDI IN" and "MIDI OUT" fields. If it does not, click the field to open a list of MIDI devices and select "ZOOM 1 Series."
- 4.4. Click the **Execute** button to start the firmware update. The progress of the firmware update appears as a bar like this.



Do not disconnect the USB cable while the firmware is being updated.

In the unlikely event that a firmware update should fail, follow the procedures from step 4.1 to update the firmware again.

- 4.5. When the firmware update completes, it will appear as follows and "Complete" will appear on the display of the G1Xon.



Click the **Exit** button to close the firmware update application. Then, disconnect the USB cable and turn the G1Xon power off.

Turn the G1Xon power on again, and confirm that the firmware versions are as follows.

BOOT:	v1.00
PRESET:	v1.00
SYSTEM:	v1.21

This completes the firmware update.