

H and F Series Stereo ASIO Driver Version History

The audio driver version is shown as below.

1. Double-click “ZOOM H and F Series Audio” icon in control panel.
2. You will find “ZOOM H and F Series High Performance ASIO Driver” indication beside the logo. The version is shown as “x.x.x” next to it.

You can always download the latest driver software for free from the web site shown below. The web site also has information on installation procedures, possible problems, and Frequently Asked Questions.

<http://www.zoom.co.jp/>

Version 3.1.0.9

- **Released as following modifications in January 2017**

1. Pro Tools supported.
2. Compliant with EV code signing certificate.