

ZOOM H and F-Series Multi Track ASIO Driver

Installation Guide (Windows)

Copyright(C) 2017 ZOOM Corporation. All Rights Reserved.

● **Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.**

Windows® is a registered trademark of Microsoft® Corporation.

Note: Other product names, registered trademarks and company names in this document are the property of their respective companies.

Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The actual content of screens and messages on the computer may differ from the illustrations used in this manual.

<Contents>

Introduction.....	3
Operation Environment Requirements	3
Precautions	3
Updating the driver	3
Installation	4
Uninstallation	8

Introduction

Thank you for downloading the ZOOM H and F-Series Multi Track Driver.
This document describes how to install and uninstall the driver.

Operation Environment Requirements

Operating system: Windows® 7(32bit, 64bit)
Windows® 8(32bit, 64bit)
Windows® 8.1(32bit, 64bit)
Windows®10(32bit, 64bit)

Precautions


- 1) Start installation and uninstallation disconnecting the product from PC.**
- 2) Before starting this application, shut down all other applications that are running.**

Updating the driver


If a ZOOM H-Series Multi Track Driver or a ZOOM H and F-Series Multi Track Driver is already installed, first uninstall the old driver. Then install the new driver.

Installation


1. Start Windows without any USB devices including the product (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Double-click on the "H_and_F-Series_Multi_Track_ASIO.exe" icon.
4. When a warning message "User Account Control Do you want to allow this app to make changes to your device?" appears, click [Yes].




5. Select language and click [OK].




6. To start the installation, click [Next].



7. The License Agreement is displayed. Read the agreement and place a check mark in the “I accept the terms in the license agreement” box to confirm your acceptance of the agreement. Then click [Next].



8. Click [Finish] to finish installation of InstallShield.



9. Next, connect the product to the computer using a USB cable.

H5 : Select [AUDIO INTERFACE] from USB menu and select [MULTI TRACK].

H6 : Select [Audio Interface] from USB menu and select [Multi Track].

F4 / F8 : Select [Audio Interface] from USB menu and select [Multi Track (PC/Mac)].


When the product is connected to Computer, the notification like “Installing device driver software” will launch and it finish automatically.

Uninstallation

1. Start Windows without any USB devices including the product (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Click on the Start→Programs→ZOOM→"Uninstall ZOOM H and F Series Multi Track Audio Driver " icon.



4. The uninstallation process starts. Confirm that you want to proceed by clicking [YES]. To cancel the process, click [NO].



*The uninstallation is completed automatically.