R16 / R24 Audio Driver for Macintosh Version History

The audio driver version is shown as below.
1. Connect the R16 / R24 to a computer as an audio interface.
2. Open "System preferences" and click "ZOOM R16(ZOOM R16_R24)" icon.
3. The version appears in "version information" field.

You can always download the latest driver software for free at the web site shown below. The web site also has information on installation procedures, possible problems, and Frequently Asked Questions.

http://www.zoom.co.jp/

Version 1.5.0

・ **Released as the version supporting MAC OS X 10.11(El Capitan) in December 2015**

Version 1.4.0

・ **Released as following bug fix in February 2012**
1. Unable to install the driver on MAC OS X 10.7.
2. The latency increases and the noise is generated while using as Audio Interface on MAC OS X 10.6.6 or later.

Version 1.3.0

・ **Released as R24 compatible in July 2010**

Version 1.2.0

・ **Released as following bug fix in April 2010**
1. Correspondence to MAC OS X 10.6 or later(64 bit mode).
2. Logic and GarageBand does not output sound rarely.

Version 1.1.0

・ **Released as following bug fix in December 2009**
1. Connected PC freezes when the R16 is used as a control surface in Mac OS X 10.5.7 or later.
2. Correspondence to Mac OS X 10.6 or later(32 bit mode only).

Version 1.0.0

・ **Released as mass production in July 2009**