Cannot output sound on Windows PC

October, 2018

If you make connection to a Windows PC with above products, audio sometimes will not be output under the following conditions.

1. Products are connecting by “ZOOM H and F Series Audio Driver” to a Windows PC.
2. The buffer size of “ZOOM H and F Series Audio Driver” set at 64 or 128 on DAW.

When you experience this problem, the following workaround may be effective:

*** When using the ZOOM H and F Series Audio Driver on DAW, select the buffer size other than 64 or 128.**

Example - Cubase LE

We apologize for any inconvenience caused.